



**ACCURAIL®**  
MADE IN THE USA

# 9900 SERIES

## 45-Foot Highway Trailer

- 1 Cut detail parts from sprues with sharp hobby knife.
- 2 Glue interior wheels to all four wheels with axles.
- 3 Slide axle assemblies through round holes in suspension frames and glue with plastic model cement.
- 4 Glue completed wheel/mounting frames into underframe.
- 5 Glue landing gear into underframe 15 notches from the nose.
- 6 Glue mud flaps into the first full notches from the back, angled away from the wheels.

