



4700 SERIES WOOD STOCK CAR

TOOLS NEEDED:

- Small Phillips Screwdriver
- Sharp Hobby Knife or Side Cutters
- Needle Nose Pliers

TRIM BRAKE STAFF	
to 1-11/16" (SCALE 12'-2")	

Cut detail parts from sprues with side cutters or a sharp hobby knife.
Use Plastic Cement or CA (Super Glue or Super Glue Gel) for small parts.

- Cement placards to outside of car as indicated on the supplemental placard location diagram.
- Cement doors in place from inside car.

Assemble underframe before installing it into the car body.

- Add brake details to underframe, then install center sills.
- Install trip pins into couplers with needle nose pliers, then install couplers into coupler pockets. Screw coupler covers into place (do not over-tighten).
- Install wheels into trucks, then install trucks into underframe. Do not over-tighten screws.
- Clean car weight before attaching to underframe with silicone adhesive, cement or double sided tape.

