

7100, 7200 SERIES WOOD BOXCAR

TOOLS NEEDED: Small Phillips Screwdriver,
Sharp Hobby Knife or Side Cutters, Needle Nose Pliers

- Cut detail parts from sprues with side cutters or a sharp hobby knife.
- Use Plastic Cement or CA (Super Glue or Super Glue Gel) for small parts.

Assemble underframe before installing it into the car body.

- Add brake details to underframe, then install center sills.
- Install trip pins into couplers with needle nose pliers, then install couplers into coupler pockets. Screw coupler covers into place (do not overtighten).
- Install wheels into trucks, then install trucks into underframe. Do not over-tighten screws.
- Clean car weight before attaching to underframe with silicone adhesive, cement or double sided tape.

