


5600 SERIES EXTERIOR POST STEEL BOX CAR

- Cut detail parts from sprues with side cutters or a sharp hobby knife.
- Use Plastic Cement or CA (Super Glue or Super Glue Gel) for small parts.
- Clean car weight before cementing to underframe.
- Assemble underframe before cementing it into car body.

IF A *PRINTED* PLUG DOOR IS SUPPLIED, IT SHOULD BE USED.

OTHERWISE, USE YOUNGSTOWN DOOR



TOOLS NEEDED:

Small Phillips Screwdriver
Sharp Hobby Knife or Side Cutters

